

Analysis Request Form

Date: _____
Sample Owner: _____
Contact Name: _____
Address: _____

Email: _____
Phone: _____

	Sample ID	System Type	% Concentration	System Capacity	Brand/Part #
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					

Notes: _____

Sampling instructions:

Glycol analysis requires 4 ounces for proper testing. Use a new, clean 4 ounce sample bottle. Locate sample port, purge the sample port into a suitable container until liquid runs clean and free of solids that may have been trapped in the sample port piping. Once sample is collected secure lid, do not overtighten as damage to the cap may occur. Label sample bottle with ID as noted above, ensure the label is legible. Place sample bottle in a mailer bottle to protect against leaks during shipment. Place sample and a copy of a completed analysis request form in a box/package and ship to the address below. Please include any notes above that may assist in diagnosing issues with the system.

Ship Samples To:

Glycol Technologies, Inc.
Attn: Lab
140 Commonwealth Drive
Warrendale, PA 15086



Proud members of the

